




1




2




3



4



5



6

1. Please check that all screws are tightened before use;
2. If the product shakes after a period of use, all screws need to be retightened.



1		1
2		2
3		2
4		2

5		4
6		4
7		20+1
8		4+1
		1

SED

